


FIG. 2









FIG. 5



000001 24920260



TO 110

FROM 128

FIG. 6B

FROM 112

116

DIALOGUE BOX DEACTIVATE EQUIPMENT

- ⇒ DISPLAY UPDATED CHARGES
- ⇒ ASK TO CONFIRM DEACTIVATION

136

USER INPUT:

- ⇒ CONFIRM DEACTIVATION
- ⇒ CANCEL AND CONTINUE USAGE

138

DIALOGUE BOX: PRINTING OF RECEIPT OPTIONS

- ◆ REQUEST PRINTING OF RECEIPT W/CC ACCOUNT
- ◆ REQUEST PRINTING OF RECEIPT WO/CC ACCOUNT
- ◆ REQUEST NO PRINTING OF RECEIPT

140

USER INPUT:

SELECT PRINTING OF RECEIPT

142

- ⇒ PRINT RECEIPT PER USER INPUT.
- ⇒ POWER OFF TO EQUIPMENT VIA SWITCHBOX.

130

DIALOGUE BOX: MAX DURATION EXCEEDED

- ⇒ DISPLAY WARNING OF MAXIMUM DURATION EXCEEDED
- ⇒ DISPLAY OPTION TO CONTINUE USAGE.

USER INPUT:

- CONTINUE USAGE
- DEACTIVATE EQUIPMENT
- NO RESPONSE


132

- ⇒ IF NO RESPONSE, POWER OFF TO EQUIPMENT
- ⇒ PRINT RECEIPT WO/CC ACCOUNT INFORMATION.

134

2025-10-27 14:20:20

FIG. 7A






FIG. 8






FIG. 9









Figure 11

002011 27920260

FIGURE 12



BEST AVAILABLE COPY




FIGURE 13
500